


User Instructions

Please Read First

- Package includes:
- 1... four panel grinder shield.
 - 2... yellow plastic eye shield clips.
 - 1... 8"x 8" clear plastic shield.
 - 1... pair of Grinder Tongs pliers.



Attach this end to Mr Splash.

The cells of the Mini Surface protect your work area by acting like a large ice cube tray that collects the grinder spray as it runs down your Mr. Splash.

The Mini Surface is a very important part of the overall function of your Grinder Combo... be sure to have one under your grinder today.

Important


Before trying to clean the eye shield... always thoroughly rinse any grinder splash from the shield by first holding it under the running water at your sink.

Using and Cleaning the Grinder Tongs



Glass stop on right-hand corner of the lower jaw.

The shape of the Tongs allow you to hold the glass flat to the grinder surface.



Increase gripping pressure and control while grinding by pressing down on the black rubber pad with the index finger of your opposite hand.

You can greatly improve the glass holding power of the Grinder Tongs by always resting a portion of the glass against the glass stop on the lower jaw... test the benefit of the stop by inserting a larger piece of glass between the jaws, but not back against the glass stop, and squeeze down hard... you will find the glass quite easy to wiggle from side to side... repeat the test with a part of the glass resting against the stop... it will be much harder to wiggle the glass.

Important Cleaning Note:

When your grinder tongs are not opening and closing as easily as when they were new... hold them under a water faucet... open and close them until they are freed up.

Thin Glass: Most stained glass is about 1/8" thick... when you need to grind 1/16" glass you can modify your grinder tongs by making plastic inserts. Cut two plastic inserts from the lid of any margarine or equivalent container... use the insert drawing as a pattern.

Place one insert between black pad and the bottom of the top jaw... this decreases the space between the top and bottom jaws... add a second insert if needed.

Thick Glass: Reverse the black rubber pad so the smooth side is turned down to the glass.